

BATTLEFIELD PNEUMATIC VALVE PART-NUMBER GUIDE

1	2	3	4	5	6	7	8	9	10	11	12	13	14	15
V	0	4	5	2	E	S	X	X	X	1	2	0	A	C

DIGITS 1,2&3	PORT SIZE
V01	M5 Size
V02	1/8" Ports
V04	1/4" Ports
V08	1/2" Ports
VM1	1/8" High Flow Mini-Size

DIGIT 7	RETURN METHOD
A	Internal Air Spring Return
D	Detent
E	Solenoid Return
P	Air Pilot Return
S	Spring Return

DIGITS 4&5	NUMBER OF WAYS & POSITIONS
3 2	3 Way Two Position
5 2	5 Way Two Position
5 3	5 Way Three Position

DIGIT 8	OPTIONS
C	Closed or Blocked Ports in Center Position
D	Dominating Pilot on One Side
L	External Pilot Supply To Solenoids
M	Built-in "Push To Connect" Fitting
O	Open Cylinder Ports in Center Position
X	No Options

DIGIT 6	ACTUATION METHOD
B	Plunger Actuated Bulkhead
E	Solenoid Actuated
F	Finger Button Actuated
I	Idle/One Way Roller Actuated
L	Lever Actuated
M	Mushroom Button Actuated
P	Air Pilot Actuated
R	Roller Actuated
T	Selector Actuated
U	Push/Pull Button Actuated
X	Mechanical Plunger Actuated

DIGITS 9 & 10	PORT FITTINGS
4X	4mm OD Push Fitting
XX	No Options

DIGITS 11-15	VOLTAGE
Nothing (no digits)	No Coils or Coil Plugs Included
120AC	120/60 (Coils & Plugs Included)
220AC	220/60 (Coils & Plugs Included)
12VDC	12V- (Coils & Plugs Included)
24VAC	24/60 (Coils & Plugs Included)
24VDC	24V- (Coils & Plugs Included)
48VAC	48/60 (Coils & Plugs Included)

Battlefield International Inc.
 1664 Kohler Road
 Cayuga, Ontario N0A 1E0
Phone (905) 772-3000
 Fax (905) 772-3099